

Reworking of Indium bump bonded pixel detectors

A.Airoidi¹, G.Alimonti², M.Amati¹, A.Bulgheroni¹, M.Caccia¹,
D.Giugni², W.Kucewicz³, F.Tomasi²

¹ Universita ' dell ' Insubria, Como, Italy

² INFN Milano, Italy

³ University of Mining and Metalurgy, Kracow, Poland

Reworking: first tests

The chip stripping machine

Conclusions: first results



Reworking?




- For pixel detectors, due to the contact density and the required single bump failure ($<10^{-4}$), the only interconnection technique is bump bonding on flipped chips
- Moving from a detector prototype to a full scale system requires a production chain optimization where hybridization plays a crucial role
- In current HEP applications up to 16 chips are attached to the same sensor; replacing a faulty chip ("reworking") could considerably improve the yield. For instance in the DELPHI pixel detector the module production yield after bonding of 16 known good chips was $\sim 80\%$ and a good part of the faults were on a single chip

Feasibility study





- The first tests have been performed at Politecnico di Milano, using a dynamometer operating in a temperature controlled environment



Results



The dispersion of the tensile strength and the quality of the re-worked chips (“mechanics grade” assessed) looks fair





Visual inspection confirms the good quality of the stripped bumps

Test conclusions



- Reworked assemblies are quite good in terms of mechanical strength and single bump failure
- Reworking with In bumps has been shown to be possible
- Care has to be taken in:
 - Removing the chip with the same planarity it has been attached (<0.1 mrad) to prevent shear stress to cause asymmetric bump breaks
 - Warming up (~ 100 C) the bonds to exploit In plastic characteristics



Conceptual design




- ...basically a microscope with few added features!
 - Micrometric positioning
 - Vacuum module holders
 - Module heater
 - Everything PC controlled



Actual machine



- Venturi vacuum pump
- Z axis
- Pick-up tool with load cell
- Hot plate with Peltier cell
- X, Y stage
- Peltier power supply
- Motion control power unit
- Everything PC controlled



Let's take a look at the single components...

Poli Comet II



Coordinate measuring machine (CMM) by Poli, Varallo, Italy that guarantees the needed planarity

Pneumatic guides of the granite moving XY axis and pneumatic balancing of the Z axis

Maximum travel of 400x300x250 mm (X,Y,Z).

Optical encoders with a resolution of 1 μm

About 1x1x1 m dimensions and 140 Kg total mass




Motion control




- NI 7344 controller up to 4 axis (3 implemented)
- Mini Maestro servo motor Pulse Width Modulation power units



PWM power units



Magneto-thermic
breakers on the motor
circuit




Z axis motor

Motion control (2)



- Performances after PID parameters have been optimized


Position Vs Time




Starting position

Target position

Position Vs Time





Position Vs Time



Motion control (3)






- A double PID has been introduced to better maintain the target position after it has been reached: the “approaching” PID is changed to the “stationary” PID after being within few microns from the target position for at least 300 ms.




The error is smaller and it does not depend any more on the approaching direction

Peltier cell



Macor thermal insulators


Hot plate with vacuum grooves




Peltier cell (2)



- Peltier cell is biased by a GPIB controlled power supply
- The hot plate temperature is read out by thermistors: a PID loop reaches and maintains the needed temperature




Pick-up tool



Load cell




- Wheatstone bridge



Touch down



Maximum load on chip is the pick-up tool weight...




...do not worry: there is also a safety stop on the Z axis position!

Software




LabView code to control the integrated system



Software (2)



First let's check and calibrate the axis motion control and the load cell...





...now we can set the target chip, go there and....

...land on it keeping an eye on the force on the load cell

Conclusions





First chips have been stripped out of a dummy module that already suffered some injuries...



Conclusions (2)



Pictures show a plastic detachment but somehow it looks like the planarity was not as required...



The chip stripping machine is working and (almost) ready!